ZLN Extra 16. Electric motor



16. Installing the wing

ZLN Extra 17. Installing the bottom cover



ZLN Extra 18. Horizontal stabilizer

Using a sharp hobby knife, carefully cut away the covering from the horizontal stabilizer slot centered on the rear of the fuselage.

Test fit the left and right stabilizer set in the horizontal stabilizer slot in the fuselage and check the alignment. Ensure that the stabilizer is centered and square to the fuselage. Adjust the alignment if necessary. Note that the stabilizer is a snug fit in the slot and may require a little sanding to achieve a perfect fit.

A=A'

ZLN Extra 19. Horizontal stabilizer



19. Horizontal stabilizer

Glue the left and right elevator halves together using **epoxy**. Be sure the alignment is correct and the horizontal stabilizer is centered in the fuselage. Remove any excess epoxy with a paper towel before it cures.

20. Vertical stabilizer

ZLN Extra 21. Vertical stabilizer

Glue the vertical fin into the fuselage, accurately align it with the rear fuselage and stand back to check it. Add the **fillets** to the front and rear of the fin.

Fillets are important. A variety of sizing fin, fillets are provided.

22. Installing the elevator

ZLN Extra 23. Elevator control horn

Control Horn
Control Horn
Control Horn